



パンフレット番号	問合せ先	電話番号
20440-304	株式会社クイックパック	0564-59-3525



» USEFUL
ユースフル



ユースフル <CN>				
CC-10162	8"ミート皿 (SM-11)	¥610	φ201×H22 (6×10)	
CC-10163	9"ミート皿 (SM-12)	¥830	φ225×H25 (6×6)	




ユースフル <CN>				
CC-10184	11.5cmタレ鉢 (SM-33)	¥260	φ115×H25 (12×18)	
CC-10185	4.75"取皿 (SM-34)	¥370	φ125×H28 (6×24)	



ユースフル <CN>				
CC-10166	7"深皿 (SM-15)	¥640	φ178×H31 (6×10)	
CC-10167	8"深皿 (SM-16)	¥800	φ203×H38 (6×8)	
CC-10168	9"深皿 (SM-17)	¥900	φ225×H41 (6×6)	
CC-10169	10"深皿 (SM-18)	¥1,400	φ253×H47 (3×6)	

» STAGE
ステージ



ステージ 白磁 <JP>				
CD-7131	13"小皿	¥500	φ135×H15	
CD-7136	16"取皿	¥600	φ160×H17	
CD-7137	18"中皿	¥700	φ180×H19	
CD-7130	25"大皿	¥1,500	φ255×H20	



ステージ 白磁 <JP>				
CD-7135	12鉢	¥500	φ120×H35	
CD-7134	14鉢	¥600	φ140×H40	
CD-7133	16鉢	¥800	φ155×H45	
CD-7132	21鉢	¥1,500	φ205×H65	

