

パンフレット番号	問合せ先	電話番号
20238-727	株式会社クイックパック	0564-59-3525

洋陶オープン 727

白 業務用食器



727-01-681 正角5時ハイレ皿 (深口) (10.5×10.5×4.5cm) 0168727001 727-02-681 正角7時ハイレ皿 (深口) (14.8×14.8×5.5cm) 0168727002 727-03-681 正角9時ハイレ皿 (深口) (19×19×5.5cm) 0168727003 727-04-681 小判5時ハイレ皿 (13×8.4×3cm) 0168727004 727-05-681 小判7時ハイレ皿 (18.5×11.8×3.2cm) 0168727005 727-06-681 小判9時ハイレ皿 (23.5×15×3.5cm) 0168727006 727-07-681 小判10時ハイレ皿 (26×16.5×3.5cm) 0168727007 727-08-681 8時正角ハイレ皿 (20.5×20.5×3.7cm) 0168727008 727-09-681 9時正角ハイレ皿 (22.8×22.8×3.9cm) 0168727009 727-10-681 12時正角ハイレ皿 (31×31×3.9cm) 0168727010 727-11-681 ラザニア (小) (21×15.5×4cm) 0168727011 727-12-681 ラザニア (中) (26.2×19.2×4.6cm) 0168727012 727-13-681 ラザニア (大) (32×23.4×6.2cm) 0168727013 727-14-681 手付13時ラザニア (32.8×17×4.5cm) 0168727014 727-15-681 14時ランドベーカー (36×21×4.5cm) 0168727015	830円 1,630円 2,500円 580円 1,290円 1,820円 2,430円 3,750円 3,960円 12,800円 2,280円 3,370円 6,600円 4,300円 1,610円	727-16-681 16時ランドベーカー (40.5×28.5×5.8cm) 0168727016 727-17-681 手付12時ミッチベーカー (30.5×18.4×4.6cm) 0168727017 727-18-681 S仕切10時ベーカー (26.2×19.4×5.4cm) 0168727018 727-19-681 12時一ツ切ベーカー (30.4×18.1×4.3cm) 0168727019 727-20-681 9時セロリー皿 (23.2×10.7×3.2cm) 0168727020 727-21-681 12時セロリー皿 (30.8×14.2×3.9cm) 0168727021 727-22-681 14時セロリー皿 (35.7×16.9×4.5cm) 0168727022 727-23-681 八角15時長角皿 (33.7×24.3×4.1cm) 0168727023 727-24-681 正角5時ハイレ皿 (浅口) (10.4×10.4×2.8cm) 0168727024 727-25-681 正角7時ハイレ皿 (浅口) (14.5×14.5×2.9cm) 0168727025 727-26-681 正角9時ハイレ皿 (浅口) (18.5×18.5×3.2cm) 0168727026 727-27-681 丸4時ハイレ皿 (10×2.6cm) 0168727027 727-28-681 丸5時ハイレ皿 (13×2.6cm) 0168727028 727-29-681 丸6時ハイレ皿 (15.7×2.8cm) 0168727029 727-30-681 丸7時ハイレ皿 (18×2.8cm) 0168727030	6,500円 3,300円 3,300円 3,300円 1,130円 2,400円 750円 3,550円 2,300円 1,630円 730円 1,630円 670円 730円 1,140円 1,610円	727-31-681 丸8時ハイレ皿 (21×3cm) 0168727031 727-32-681 丸9時ハイレ皿 (22.7×3.2cm) 0168727032 727-33-681 丸10時ハイレ皿 (25.5×3.2cm) 0168727033 727-34-681 丸11時ハイレ皿 (29.5×4cm) 0168727034 727-35-681 丸12時ハイレ皿 (31×4cm) 0168727035 727-36-681 13時ミツ切角ランチ (29×22×2.6cm) 0168727036 727-37-681 101/2時ミツ切角ランチ (28.6×21.6×2.1cm) 0168727037 727-38-681 15時E角角ランチ (33.7×23.4×2.4cm) 0168727038 727-39-681 耳付81/2時グラタン (21.2×10.6×3.7cm) 0168727039 727-40-681 8時ランチ丸皿 (20×2.4cm) 0168727040 727-41-681 9時ランチ丸皿 (23×2.8cm) 0168727041 727-42-681 10時ランチ丸皿 (25.5×3cm) 0168727042 727-43-681 12時正角盛皿 (29.4×29.4×3.1cm) 0168727043 727-44-681 14時長角皿 (36×24.4×3.6cm) 0168727044 727-45-681 16時長角皿 (42×26×4cm) 0168727045	1,990円 2,230円 2,780円 3,900円 5,600円 3,600円 700円 3,600円 1,190円 990円 1,190円 700円 4,700円 3,650円 5,650円	727-46-681 18時長角皿 (47.1×29.2×4.4cm) 0168727046 727-47-681 10時ランチプラター (26×18.2×3cm) 0168727047 727-48-681 12時ランチプラター (30.7×21.4×3cm) 0168727048 727-49-681 12時長角ケーキプレート (30.7×19.6×1.5cm) 0168727049 727-50-681 131/2時長角ケーキプレート (34.2×22.8×1.5cm) 0168727050 727-51-681 71/2時長角皿 (18×12×1.9cm) 0168727051 727-52-681 9時長角皿 (22×15×2.3cm) 0168727052 727-53-681 10時長角皿 (26×17.5×2.5cm) 0168727053 727-54-681 12時長角皿 (29.5×19.7×2.6cm) 0168727054 727-55-681 フィッシュプレート (小) (42×17.8×3.5cm) 0168727055 727-56-681 フィッシュプレート (大) (54×22×4cm) 0168727056 727-57-681 101/2時丸ケーキプレート (26.5×1.5cm) 0168727057 727-58-681 12時丸ケーキプレート (29.2×1.6cm) 0168727058 727-59-681 13時丸ケーキプレート (32×1.8cm) 0168727059	12,800円 1,300円 1,980円 4,700円 5,350円 680円 1,000円 1,550円 2,250円 4,000円 5,900円 3,600円 4,900円 5,600円
--	---	---	--	---	--	---	---