




パンフレット番号	問合せ先	電話番号
20599-113	株式会社クイックパック	0564-59-3525




177 00 061  
27cm  
ソフトスクエアプレート  
D-27 H-4 ¥4,200




177 00 062  
24cm  
ソフトスクエアプレート  
D-24 H-3.6 ¥3,400



177 00 064  
21cm  
ソフトスクエアプレート  
D-21 H-3 ¥2,700



177 00 065  
18cm  
ソフトスクエアプレート  
D-18 H-2.6 ¥2,300



177 00 066  
16cm  
ソフトスクエアプレート  
D-16 H-2.4 ¥2,100



177 00 026  
15cmマルチボウル  
D-15 H-8.3 ¥1,800



177 00 027  
13.5cmマルチボウル  
D-13.5 H-7.5 ¥1,300



177 00 028  
12cmマルチボウル  
D-12 H-6.9 ¥1,100



177 00 029  
11cmマルチボウル  
D-11 H-6.3 ¥950



177 00 030  
9cmマルチボウル  
D-9 H-6.2 ¥800



177 00 023  
17cm洋ボウル  
D-17 H-7.1 ¥2,100



177 00 025  
13cm洋ボウル  
D-13 H-5.4 ¥1,300



177 00 032  
15cm多用丼  
D-15 H-8.1 ¥2,100



177 00 033  
13cm多用丼  
D-13.3 H-7.2 ¥1,700



177 00 034  
11.5cm多用丼  
D-11.5 H-6.1 ¥1,300



176 00 046  
16.5cm  
ソフトスクエアボウル  
D-16.7 H-7 ¥2,500



176 00 047  
14.5cm  
ソフトスクエアボウル  
D-14.6 H-6.3 ¥1,800



176 00 048  
12cm  
ソフトスクエアボウル  
D-12.1 H-5.3 ¥1,400



176 00 049  
9.5cm  
ソフトスクエアボウル  
D-9.6 H-4.3 ¥1,000



176 00 044  
13.5cm  
ソフトスクエア深皿  
D-13.8 H-4.2 ¥1,600



176 00 045  
11.5cm  
ソフトスクエア深皿  
D-11.6 H-3.4 ¥1,200



177 00 051  
カプチーノカップ  
L-11.1 S-8.4 H-7.9 C-250cc ¥1,100

127 00 055  
兼用ソーサー  
D-15.2 H-2.2 ¥700



177 00 052  
コーヒーカップ  
L-10.1 S-7.5 H-6.7 C-160cc ¥950

177 00 054  
コーヒーソーサー  
D-14.5 H-1.8 ¥850



177 00 058  
エスプレッソカップ  
L-8.6 S-6.3 H-5.9 C-105cc ¥850

170 00 059  
エスプレッソソーサー  
D-12.8 H-1.7 ¥650