

パンフレット番号	問合せ先	電話番号
20684-128	株式会社クイックパック	0564-59-3525

飯碗

飯碗・茶碗

					
569 11 028 風砂 12cm飯碗 D-12 H-6.4 C-370cc ¥1,400	569 81 028 氷華 12cm飯碗 D-12 H-6.4 C-370cc ¥1,400	569 21 028 穂波 12cm飯碗 D-12 H-6.4 C-370cc ¥1,400	569 82 028 蒼翠 12cm飯碗 D-12 H-6.4 C-370cc ¥1,400	569 42 028 紅月 12cm飯碗 D-12 H-6.4 C-370cc ¥1,400	569 00 028 白虎 12cm飯碗 D-12 H-6.4 C-370cc ¥1,300
					
569 41 028 朱雀 12cm飯碗 D-12 H-6.4 C-370cc ¥1,300	538 00 020 白涼 飯碗 D-11 H-5.9 C-320cc ¥1,200	538 71 020 静寂 飯碗 D-11 H-5.9 C-320cc ¥1,200	538 31 020 漆黒 飯碗 D-11 H-5.9 C-320cc ¥1,200	545 26 030 ローゼ 飯碗 D-11.8 H-6.4 C-320cc ¥900	545 27 030 若草 飯碗 D-11.8 H-6.4 C-320cc ¥900
					
545 88 030 月の香 飯碗 D-11.8 H-6.4 C-320cc ¥900	567 81 133 藍七宝 飯碗 D-12.3 H-6.5 C-380cc ¥1,300	567 82 133 藍波花 飯碗 D-12.3 H-6.5 C-380cc ¥1,300	567 83 133 藍格子 飯碗 D-12.3 H-6.5 C-380cc ¥1,300	567 84 133 藍花 飯碗 D-12.3 H-6.5 C-380cc ¥1,300	530 31 030 黒洋 リップル茶碗 D-11.4 H-6.3 C-340cc ¥850
					
530 79 030 銀彩ブルー リップル茶碗 D-11.4 H-6.3 C-340cc ¥850	530 94 030 花の舞 リップル茶碗 D-11.4 H-6.3 C-340cc ¥900	530 84 030 波の舞 リップル茶碗 D-11.4 H-6.3 C-340cc ¥900	530 74 030 風の舞 リップル茶碗 D-11.4 H-6.3 C-340cc ¥900	530 34 030 雪の舞 リップル茶碗 D-11.4 H-6.3 C-340cc ¥900	530 81 030 藍日傘 リップル茶碗 D-11.4 H-6.3 C-340cc ¥850

飯器

				
510 27 035 益子ツタ 飯器 D-13 H-7.8 C-595cc ¥950	510 77 035 グリーン志野 飯器 D-13 H-7.8 C-595cc ¥950	510 61 035 美濃伊賀 飯器 D-13 H-7.8 C-595cc ¥950	510 93 035 錦天目 飯器 D-13 H-7.8 C-595cc ¥950	510 08 035 タイスキ 飯器 D-13 H-7.8 C-595cc ¥1,000

ころころ碗

					
510 01 050 ねーじゅ ころころ碗 D-10.6 H-7 C-345cc ¥850	510 31 050 黒洋 ころころ碗 D-10.6 H-7 C-345cc ¥850	510 38 050 山がすみ ころころ碗 D-10.6 H-7 C-345cc ¥850	510 79 050 銀彩ブルー ころころ碗 D-10.6 H-7 C-345cc ¥850	510 35 050 志野化粧 ころころ碗 D-10.6 H-7 C-345cc ¥850	510 66 050 白露 ころころ碗 D-10.6 H-7 C-345cc ¥850