

Catalogue No.

20330-1166



※軽くて、破損に強い！ 雲高月盛器 1166



2-1166-1 朱天黒 ￥1,350

雲高月盛皿のみ [A]
241×212×13 G1-156-1 (9-570-1)

2-1166-2 ￥500

雲高月盛皿用低丸足 [A]
φ112×26 G1-156-2 (9-570-2)



2-1166-3 二色金箔 ￥2,650

雲高月盛皿のみ [A]
241×212×13 G1-156-3 (9-570-3)

2-1166-4 ￥550

雲高月盛皿高三つ足 [A]
φ109×60 G1-156-4 (9-570-4)

●低丸足・高三つ足とも雲高月皿にセット可能。



隅丸高月盛器



2-1166-5 二色金箔 ￥2,200

7寸 隅丸高月盛皿板 [A]
174×174×4 G1-156-5 (9-570-5)

2-1166-6 朱 ￥1,150

7寸 隅丸高月盛皿 [A]
212×212×18 G1-156-6 (9-570-6)

2-1166-7 ￥500

7寸 隅丸高月盛皿用低足 [A]
120×120×34 G1-156-7 (9-570-7)

2-1166-8 朱 ￥950

7寸 隅丸高月盛皿板 [A]
174×174×4 G1-156-8 (9-570-8)

2-1166-9 溜 ￥1,400

7寸 隅丸高月盛皿 [A]
212×212×18 G1-156-9 (9-570-9)


2-1166-10 ￥700

7寸 隅丸高月盛皿用高足 [A]
130×130×70 G1-156-10 (9-570-10)



●低足・高足とも7寸隅丸高月皿、7寸正角高月皿にセット可能。

正角高月盛器



2-1166-11 日の出 ￥1,450

7寸 正角高月盛皿 [A]
212×212×15 G1-156-11 (9-570-11)

2-1166-12 ￥500

7寸 正角高月盛皿用低足 [A]
120×120×34 G1-156-12 (9-570-12)

2-1166-13 金パール ￥1,450

7寸 正角高月盛皿 [A]
212×212×15 G1-156-13 (9-570-13)

2-1166-14 ￥700

7寸 正角高月盛皿用高足 [A]
130×130×70 G1-156-14 (9-570-14)



●低足・高足とも7寸隅丸高月皿、7寸正角高月皿にセット可能。