

Catalogue No.
20339-176

段無 マークは身の内側に段がありません。 (TA) マークは 洗浄機使用 OK!

(TA) 煮物椀 176

お
椀



7-176-1 1-206-1
(TA) 5.5寸煮物椀 朱布目
¥2,100 (16.7φ×10.1) 桐60



7-176-2 1-206-2
(TA) 5.5寸煮物椀 溜布目
¥2,300 (16.7φ×10.1) 桐60



7-176-3 W-7-22
(TA) 5.5寸煮物椀 枺布目
¥2,400 (16.7φ×10.1) 桐60



7-176-4 W-14-79
(TA) 5.5寸小植木目椀 黒内朱
¥2,100 (16.7φ×10.1) 桐60



7-176-5 W-14-80
(TA) 5.5寸小植木目椀 溜
¥2,300 (16.7φ×10.1) 桐60



7-176-6 W-14-81
(TA) 5.5寸小植木目椀 枺
¥2,400 (16.7φ×10.1) 桐60



7-176-7 W-14-82
(TA) 6寸小植煮物椀 朱布目
¥2,400 (18φ×10.5) 桐60



7-176-8 W-14-83
(TA) 6寸小植煮物椀 溜布目
¥2,700 (18φ×10.5) 桐60



7-176-9 W-14-84
(TA) 6寸小植煮物椀 枺布目
¥2,800 (18φ×10.5) 桐60



7-176-10 W-14-85
(TA) 6寸小植煮物椀 黒木目内朱
¥2,400 (18φ×10.5) 桐60



7-176-11 W-14-86
(TA) 6寸小植煮物椀 溜木目
¥2,700 (18φ×10.5) 桐60



7-176-12 W-14-87
(TA) 6寸小植煮物椀 枺木目
¥2,800 (18φ×10.5) 桐60