

Catalogue No.

20599-131

BANQUET



169 00 060
31cm
スクエアプレート
D-31.2 H-4 ¥8,200

169 00 061
26.5cm
スクエアプレート
D-26.5 H-3.2 ¥4,900

169 00 063
23cm
スクエアプレート
D-23.1 H-2.8 ¥3,900

169 00 064
20cm
スクエアプレート
D-20.1 H-2.4 ¥3,100

169 00 065
18cm
スクエアプレート
D-18.3 H-2.2 ¥2,600

169 00 066
16cm
スクエアプレート
D-16.1 H-2.2 ¥2,200




169 00 045
33cm角プラター
L-33 S-22.1 H-3.2 ¥6,300




169 00 046
30.5cm角プラター
L-30.4 S-20.2 H-2.8 ¥5,000



169 00 047
28cm角プラター
L-28 S-18.7 H-2.7 ¥4,200



169 00 094
33cm細長角プラター
L-33.2 S-12.4 H-2.7 ¥4,200



169 00 095
30.5cm細長角プラター
L-30.2 S-11.4 H-2.3 ¥3,100



169 00 011
23cmスクエア深皿
D-23.2 H-4.7 ¥4,500



169 00 012
21cmスクエア深皿
D-21 H-4.3 ¥3,500




169 00 023
18cmボウル
D-18 H-5.6 ¥3,000



169 00 024
16cmボウル
D-16.2 H-4.9 ¥2,500



169 00 025
14cmボウル
D-14.1 H-4.4 ¥2,200



169 00 026
12cmボウル
D-12.3 H-3.7 ¥1,700



169 00 027
10cmボウル
D-10 H-3.2 ¥1,300



169 00 028
8cmボウル
D-8.3 H-2.8 ¥1,100



169 00 037
10.5cm深ボウル
D-10.7 H-5.8 ¥1,700




169 00 038
9cm深ボウル
D-9.1 H-5.1 ¥1,400



169 00 039
7.5cm深ボウル
D-7.6 H-4.5 ¥1,200



169 00 018
9cmスクエア深皿
D-9 H-2 ¥1,200



169 00 092
4菜皿
D-27.3 H-1.5 ¥5,200



169 00 097
3連菜
L-25 S-8.3 H-2.8 ¥2,900



169 00 098
2連菜
L-16.8 S-8.3 H-2.8 ¥1,800



169 00 052
コーヒーカップ
L-12 S-9.5 H-7.4 C-180cc ¥1,100

169 00 055
コーヒーソーサー
D-12.8 H-1.6 ¥1,100