


Catalogue No.

20599-219

GALAXY



111 11 040
36.5cmプラター
L-36.5 S-26.2 H-4
¥6,500

111 11 043
31.5cmプラター
L-31.8 S-22 H-3.7
¥4,700

111 11 045
26cmプラター
L-26.2 S-18.2 H-2.7
¥2,900

111 11 046
24cmプラター
L-24 S-17 H-2.7
¥2,100

111 11 049
18.5cmプラター
L-18.8 S-12.2 H-2.3
¥1,600



111 11 013
22cm/パスタボウル
D-22.3 H-5.4
¥2,500



111 11 012
18cm/パスタボウル
D-18.1 H-5
¥1,400



111 11 072
グラタン
L-16.1 S-14.5 H-4.7
¥2,200



111 11 095
28.5cmラザニア
L-28.5 S-20.4 H-4.7 ¥4,300



111 11 097
19cmラザニア
L-19.2 S-12.2 H-3.4 ¥1,700



111 11 015
24cmスープボウル
D-24 H-6 ¥2,200



111 11 016
20cmスープボウル
D-20 H-5.3 ¥1,200



110 11 093
16cm深取り皿
D-16.2 H-3.5 ¥950



110 11 094
15cm深取り皿
D-15 H-3.2 ¥850



110 11 095
13cm深取り皿
D-13 H-3.1 ¥750



110 11 018
10cmタレ皿
D-10 H-2.7 ¥700



111 11 054
両手付スープカップ
L-17.8 S-12.3 H-6.5
C-380cc ¥1,500



111 11 055
兼用ソーサー
D-15.3 H-2.5
¥700



111 11 059
片手スープカップ
L-15.5 S-11.4 H-6
C-250cc ¥1,500



111 11 060
シュガー
D-8 H-10
C-280cc ¥1,900



111 11 063
クリーマー
L-10.4 S-7.4 H-6.7
C-160cc ¥1,600



111 11 050
マグカップ
L-12.2 S-8.9 H-9.8 C-340cc ¥1,100



111 11 051
アメリカンカップ
L-11.5 S-8.8 H-8 C-270cc ¥800



111 11 052
コーヒーカップ
L-10.5 S-7.8 H-7.3 C-180cc ¥750



111 11 053
ティーカップ
L-12.5 S-9.9 H-5.8 C-240cc ¥800

111 11 055
兼用ソーサー
D-15.3 H-2.5 ¥700

111 11 056
コーヒーソーサー
D-14.3 H-2.5 ¥650

111 11 055
兼用ソーサー
D-15.3 H-2.5 ¥700