

Catalogue No.

20599-244



111 86 002
26cmディナー皿
D-26 H-3.2 ¥2,400

111 86 004
23cmミート皿
D-23.2 H-3 ¥1,700

111 86 006
19.5cmケーキ皿
D-19.8 H-2.9 ¥1,300

111 86 008
15cmパン皿
D-15 H-2.5 ¥950



111 86 097
19cmラザニア
L-19.7 S-12.2 H-3.5 ¥1,900



111 86 072
グラタン
L-16 S-14.4 H-5.1 ¥2,400



161 86 012
22cmバスタボウル
D-22.4 H-3.7 ¥1,700



113 86 044
28.5cmオーバルプラター
L-29.1 S-22.5 H-4 ¥3,600



113 86 071
27cmオーバルペーカー
L-27 S-17.2 H-5.5 ¥3,600



111 86 043
31.5cmプラター
L-31.8 S-22 H-3.7
¥5,100



111 86 045
26cmプラター
L-26.2 S-18.2 H-2.7
¥3,300



111 86 046
24cmプラター
L-24 S-17 H-2.7
¥2,400



111 86 021
23cmボウル
D-23.2 H-8.3
¥2,900



111 86 023
20cmボウル
D-20 H-7
¥2,700



111 86 024
17cmボウル
D-17 H-6.3
¥1,600



111 86 025
13.5cmボウル
D-13.7 H-5.5
¥1,000



111 86 027
10cmボウル
D-10.2 H-4.1
¥850



113 86 063
クリーマー
L-10.7 S-8.1 H-8
C-200cc ¥1,700



113 86 051
ダイナマグカップ
L-12.2 S-8.8 H-9.3
C-345cc ¥1,500



113 86 052
ダイナーカップ
L-11.4 S-8 H-8.6
C-240cc ¥1,400



113 86 053
ダイナーコーヒーカップ
L-10.1 S-7.5 H-7.8
C-200cc ¥1,300



113 86 050
高台削リマグカップ
L-12.2 S-8.8 H-10.4
C-330cc ¥1,500



111 86 052
コーヒーカップ
L-10.5 S-7.8 H-7.3
C-180cc ¥1,000



111 86 053
ティーカップ
L-12.5 S-9.9 H-5.8
C-240cc ¥1,100



113 86 056
ダイナースープカップ
L-13.2 S-10.5 H-6.3
C-340cc ¥1,700



111 86 058
片手スープカップ
L-15 S-12.1 H-6.4
C-340cc ¥1,500

161 86 055
モア兼用ソーサー
D-15.3 H-2
¥750

111 86 056
コーヒーソーサー
D-14.3 H-2.5
¥750

161 86 055
モア兼用ソーサー
D-15.3 H-2
¥750

111 86 056
コーヒーソーサー
D-14.3 H-2.5
¥750

111 86 055
兼用ソーサー
D-15.3 H-2.5
¥800

111 86 055
兼用ソーサー
D-15.3 H-2.5
¥800

111 86 055
兼用ソーサー
D-15.3 H-2.5
¥800