

Catalogue No.

20599-55

Fonte




171 00 090
36cmオーバル皿
L-36.2 S-16.3 H-3 ¥7,000



171 00 092
31cmオーバル皿
L-31.3 S-14 H-3 ¥3,800



171 00 093
26cmオーバル皿
L-26.4 S-11.5 H-2.2 ¥2,200



171 00 081
35.5cmオーバル長皿
L-35.8 S-12 H-2.5 ¥4,900



171 00 082
33cmオーバル長皿
L-33.3 S-10.9 H-2.3 ¥3,000



171 00 083
30.5cmオーバル長皿
L-30.7 S-10.1 H-2.1 ¥2,800



171 00 084
27.5cmオーバル長皿
L-27.7 S-8.9 H-1.8 ¥2,400



171 00 095
24.5cmオーバル長皿
L-24.6 S-7.9 H-1.6 ¥1,700



172 00 033
20.5cmデュードロップ浅ボウル
L-20.5 S-16.5 H-4.4 ¥3,000



172 00 035
17.5cmデュードロップ浅ボウル
L-17.8 S-14.2 H-4 ¥1,900



172 00 036
14.5cmデュードロップ浅ボウル
L-14.7 S-11.5 H-3.6 ¥1,600



172 00 037
12cmデュードロップ浅ボウル
L-12 S-9.3 H-3.3 ¥1,200



171 00 014
17.5cmスープボウル
D-17.6 H-5.2 ¥1,100



171 00 015
15.5cmフルーツボウル
D-15.5 H-4.6 ¥950



171 00 016
13cmフルーツボウル
D-13.4 H-4.1 ¥800



172 00 013
19cmデザートボウル
D-19.4 H-4.9 ¥1,300



172 00 014
16cmデザートボウル
D-16 H-4.2 ¥1,100



172 00 016
13cmデザートボウル
D-13.3 H-3.4 ¥950



171 00 054
両手スープカップ
L-15.6 S-10.4 H-5.6
C-270cc ¥1,600
170 00 055
兼用ソーサー
D-15.2 H-2.2 ¥700



171 00 056
片手スープカップ
L-12.9 S-10.4 H-5.6
C-270cc ¥1,500
170 00 055
兼用ソーサー
D-15.2 H-2.2 ¥700



171 00 051
カプチーノカップ
L-11.5 S-9 H-6.7 C-205cc ¥1,100
170 00 055
兼用ソーサー
D-15.2 H-2.2 ¥700



171 00 052
コーヒーカップ
L-10.8 S-8.3 H-6.2 C-160cc ¥1,000
170 00 055
兼用ソーサー
D-15.2 H-2.2 ¥700



171 00 058
エスプレッソカップ
L-9 S-7.2 H-5.3 C-100cc ¥850
170 00 059
エスプレッソソーサー
D-12.8 H-1.7 ¥650



197 00 658
エスプレッソカップ 小
L-9 S-6.7 H-4.6 C-65cc ¥800
170 00 059
エスプレッソソーサー
D-12.8 H-1.7 ¥650