

Catalogue No.

20674-643

34-643 パーティー皿・寿司盛器・寿司盛舟



① 1-442-3
[A] 立食パーティー皿 黒天朱
¥1,400 (21.5×17.5×3) 棚100

② 1-442-6
[A] 宴パーティー皿 朱天黒
¥1,900 (25.7×18.2×2) 棚80

1-534-4A [竹] 竹ス (14.8×14.8cm)
¥450 (14.8×14.8)
1-559-15 [TA] DXつゆ入れ 外朱天朱
¥950 (8.8φ×6.3) 棚200



③ 1-711-2
[A] 立食パーティー皿 ブルー真珠天黒
¥1,500 (21.5×17.5×3) 棚100



⑥ F-1-70
[TA] 平安箱 銀朱
¥2,250 (20.2×11.9×4.4) 棚80



④ 宴パーティー皿
1-442-7 [A] 黒天朱
¥1,900 (25.7×18.2×2) 棚80



⑤ F-1-69
[TA] 平安箱 黒内朱
¥2,200 (20.2×11.9×4.4) 棚80
S-8-97 [竹] 竹ス1枚
¥430 (11×11)
1-339-22 [TA] 2.3寸丸鉢 朱内黒
¥630 (7φ×3.6) 棚200

日野盛器

寿
司



⑦ 1-624-1 [A] 5.5寸日野盛器 黒
¥2,200 (16.8×16.8×6.5) 棚60



⑧ 1-625-1 [A] 6寸角透かし盛器 黒天朱
¥1,850 (17.8×17.8×4.3) 棚60



⑨ 1-625-3 [A] 6寸角足付透かし盛器 黒天朱
¥3,100 (17.8×17.8×7.1) 棚60

1-624-3 [A] 日野盛器用中皿 金/朱
¥1,500 (15.3×15.3×0.3) 棚200

1-625-6 [A] 6寸角透かし盛器用中皿 朱千筋/金
¥1,650 (16.8×16.8×0.3) 棚200

1-625-6 [A] 6寸角透かし盛器用中皿 朱千筋/金
¥1,650 (16.8×16.8×0.3) 棚200



⑩ 1-626-2 [A] 7寸角足付透かし盛器 黒
¥4,000 (21×21×8.4) 棚40



⑪ 1-626-8 [A] 8寸角高型透かし盛器 黒
¥2,900 (23.8×23.8×6.2) 棚40



⑫ 1-628-10 [A] 尺0寸長手透かし盛器 黒
¥2,600 (29.8×14.8×4.8) 棚60

1-626-3 [A] 7寸角透かし盛器用中皿 朱千筋/金
¥1,700 (19.5×19.5×0.3) 棚100

1-628-14 [A] 尺0寸長手透かし盛器用中皿 朱/金
¥2,700 (28.5×13.5×0.3) 棚100

寿司盛舟



⑬ 1-708-1
[M] 尺0寸タレ付舟 白木内黒塗
¥6,500 (29.3×14.1×6.2) 棚60



⑭ 1-708-3-3A
[A] 尺1寸タレ付舟 白木
(目皿付)
¥6,200 (33×17×7) 棚60



⑮ 1-708-2
[A] 尺5寸將軍舟 白木
¥5,250 (45.5×18.6×15.5) 棚20



⑯ 1-708-2-2A
[A] 尺1寸タレ付舟 パール波内黒
(目皿付)
¥4,400 (33×17×7) 棚60



⑰ 1-708-7
[A] 尺5寸將軍舟 溜波
¥5,100 (45.5×18.6×15.5) 棚20



⑱ 1-709-1
[A] 2尺1寸ABS大漁舟
¥29,500 (63×22×20) 棚6

※ご使用時はシート等をご利用下さい。