

Catalogue No.

20677-57

Sashimi bowl 向付

57

Japanese Tableware



05701-140 乾山鶴絵六角皿
6,400円 30入 (20×17.5×3.5cm)



05702-140 乾山山茶花六角皿
5,000円 30入 (20×17.5×3.5cm)



05703-470 乾山山水扇型向付
5,400円 40入 (24×11.2×4cm)



05704-140 染付山水菱形向付
4,750円 40入 (24×13.7×3.6cm)



05705-130 雲母金三日月鉢
5,500円 40入 (22.5×11×12cm)



05706-130 雲母銀三日月鉢
5,500円 40入 (22.5×11×12cm)



05707-460 銀彩渦巻向付
5,500円 (21.8×3.7cm)



05708-460 内青白渦巻向付
5,100円 (21.8×3.7cm)



05709-460 ピンク吹渦巻向付
5,100円 (21.8×3.7cm)



05710-460 艶紫渦巻向付
5,100円 (21.8×3.7cm)



05711-470 朱刷毛目金彩舟型向付
4,400円 40入 (29.3×10.1×6cm)



05712-580 金吹雪向付
4,890円 60入 (22.8×10×7cm)



05713-170 アメ釉内シルバーくびれ7寸向付
5,280円 (22.1×9×5.9cm)




05714-170 アメ釉内ゴールドくびれ7寸向付
5,280円 (22.1×9×5.9cm)



05715-250 測プラチナ四色両上り向付
4,500円 (20×10.5×4.5cm)



05716-470 サビ吹ゴールド菱型面上り7.3寸鉢
3,700円 100入 (21.2×12.5×5.6cm)



05717-170 染付春秋丸紋半開扇型向付
4,950円 40入 (22.3×11.8×5.5cm)



05718-570 呉須刷毛目舟形向付
3,600円 40入 (23.5×10×6cm)



05719-130 測錆マリンブルー両上り向付
3,850円 50入 (24.7×10.6×8.5cm)



05720-130 いぶし釉扇鉢
3,800円 (21.2×17.8×5.7cm)



05721-030 赤彩花々タラ三足皿
2,900円 25入 (21×21×4.5cm)



05722-100 緑彩舟型小鉢
1,100円 80入 (20.3×9.3×6.7cm)



05723-100 織部十草舟型小鉢
1,100円 80入 (20.5×9.6×6.7cm)



05724-100 窯変(白)舟型小鉢
1,100円 80入 (20.5×9.6×6.7cm)

Large bowl

Sashimi bowl

Small bowl

Tiny bowl, Shokado bento

Lidded bowl

Lidded bowl for Steamed dish

Large plate

Round/long plate (large)

Square plate (large)

Long plate (large)

Appetizer plate (large)

Round plate (middle)

Tempura plate

Small bowl

Round plate (small)

Square plate (middle)

Square/ Appetizer plate (small)

Long plate (middle)

Appetizer plate

Rectangle/ Appetizer plate (middle)

Plate

Small plate

Small plate